

3000 > 

TEHNIČNI PODATKI								
Modello	Continui		Emergenza		Giri entrata	HP trattore		
	[KVA]	[KW]	[KVA]	[KW]		Hp	Kg	mm
CGM 10TR	10	8	11	8,8	440	20	95	900x850x800h
CGM 16TR	16	12,8	17,5	14	440	30	125	900x850x800h
CGM 22TR	22	17,6	24,2	19,3	440	45	140	900x850x800h
CGM 27TR	27	21,6	29,7	23,7	440	45	150	950x950x900h
CGM 30TR	30	24	33	26,4	440	60	210	950x950x900h
CGM 40TR	40	32	44	35,2	440	75	233	950x950x900h

1500 > 

TEHNIČNI PODATKI								
Modello	Continui		Emergenza		Giri entrata	HP trattore		
	[KVA]	[KW]	[KVA]	[KW]		Hp	Kg	mm
CGM 10TRL	10	8	11	8,8	430	20	135	900x850x800h
CGM 15TRL	15	12	16,5	13,2	430	30	150	900x850x800h
CGM 20TRL	20	16	22	17,6	430	45	205	900x850x800h
CGM 25TRL	25	20	27,5	22	430	45	230	950x950x900h
CGM 30TRL	30	24	33	26,4	430	60	241	950x950x900h
CGM 42TRL	42	33,6	46,2	37	430	80	320	1100x950x1270h
CGM 50TRL	50	40	55	44	395	100	408	1150x950x1000h
CGM 60TRL	60	48	66	52,8	420	120	425	1100x950x1270h
CGM 75TRL	75	60	82,5	66	395	130	440	1150x950x1000h
CGM 85TRL	85	68	93,5	74,8	395	130	450	1100x950x1270h